

Automotive AI BOX

Installation and first-run checklist

Follow these four steps to bring wireless CarPlay or Android Auto to a factory head unit. The box draws power from the vehicle USB port and needs no dashboard removal.

KEY FEATURES

- Step 1 - Confirm fitment. Check that your factory head unit supports wired CarPlay or Android Auto. If it does, the box can upgrade it to wireless.
- Step 2 - Connect. Plug the AI BOX into the factory USB data port using the supplied USB-C cable. Use the data port, not a charge-only port.
- Step 3 - Pair. Turn on the ignition. The head unit detects the box within 20-30 seconds. Open Bluetooth settings on your phone and pair with the name shown on screen.
- Step 4 - Verify. Play audio and use steering wheel controls to confirm the connection. If pairing fails, remove the phone from the head unit pairing list and repeat step 3.

SPECIFICATIONS

Power source	
Boot time	Approximately 20-30 seconds after ignition
Supported phones	iPhone with wireless CarPlay support, Android 11 or above for Android Auto
Firmware update	Over the air through the companion app, or by USB with a supplied image
Operating temperature	-20 C to +70 C
Storage conditions	-40 C to +85 C, keep away from direct sunlight when unplugged

IN THE BOX

- AI BOX main unit
- USB-C cable
- Mounting base
- Quick start card

WHERE IT FITS

- Factory head units with wired CarPlay
- Factory head units with wired Android Auto
- Vehicles where the owner wants video casting